

HOOD





HLF **Heavy Loading Filter**





NOTE

Generally, start with the ML (Medium/Large) size face/head cover, unless the user has a particularly small size head.

Assemble and Don Battery and Belt





1. Remove a fully charged Battery from the Charger and place the Belt 2. Place the Belt comfortably around the waist fully under the Battery Clip so that the Clip Detent touches the Clip, Metal-to Metal.



with the Battery near the side-back of the right hip and lock the buckles together.


Assemble The Hood to The Helmet






1. Snap Lens Front Alignment Hole over Helmet Front Mounting Post. Attach each Lens Side Alignment Holes over Helmet Side Mounting Posts.









Don the Assembled Helmet and Hood



1. Connect Helmet Power Cord to Battery, loosen Headband Ratchet Knob.




2. Pull Cuff top edge down, place Chin into Cuff (Single Hood Only). Pull Helmet down onto Head.



3. Check Cuff Tension¹ around Face (Single Hood Only). Tighten Ratchet knob to secure Helmet for all activities1



4. Pull Hood Shroud(s) down to shoulder level.



1 Ensure less than one-half inch between Eyebrows and Helmet front bottom so Safety LEDs are easily seen.

Complete Donning



1. Place inner Shroud inside 2. Cup HLF back under body gown (Double Hood Only).Pull outer Shroud down fully.





Helmet back; Pull HLF foreward and down fully covering Hood Filter.



3. Optional Filter Fluid Protection for PB Hoods Only: Place HFR FCC down onto Helmet, covering HLF and Filter.



4. Secure all ties.

Doff and Disassembly

Reverse Donning and Assembly steps. Disconnect Battery from Helmet Power

Connect the Battery to a Charger.



Ready for Next Use

Dispose of single use items per institutional protocol for contaminated waste.

Wipe down all reusable item surfaces with alcohol based wipes.



